

MONTAGEANLEITUNG

sun-10375abc · Volvo XC90 2015-

DE: Montageanleitung

MT: Istruzzjonijiet għall-assemblaġġ

EN: Installation instructions

NL: Montagehandleiding

DK: Installationsvejledning til

PL: Instrukcje montażu

EE: Paigaldusjuhised

PT: Instruções de montagem

FI: Paigaldusjuhised

RO: Instrucțiuni de asamblare

FR: Instructions de montage

SE: Monteringsanvisningar

GR: Οδηγίες συναρμολόγησης

SK: Návod na montáž

IE: Treoracha tionóil

SI: Navodila za sestavljanje

IT: Istruzioni di montaggio

ES: Instrucciones de montaje

HR: Összeszerelési útmutató


CZ: Návod k montáži

LV: Montāžas instrukcija

HU: Összeszerelési útmutató

LT: Surinkimo instrukcijos

BG: Инструкции за сглобяване





2x A1


2x A2

2x B


1x C



8x SC27



2x SC8-20






2x SC9-20

1x

MONTAGEANLEITUNG

sun-10375abc · Volvo XC90 2015-



MONTAGEANLEITUNG

sun-10375abc · Volvo XC90 2015-



1



2



3



4

MONTAGEANLEITUNG

sun-10375abc · Volvo XC90 2015-



MONTAGEANLEITUNG

sun-10375abc · Volvo XC90 2015-

