

MONTAGEANLEITUNG

sun-10507abc · Ford Capri 2024- SunClip Auto Sonnenschutz

DE: Montageanleitung

MT: Istruzioni per l'installazione

EN: Installation instructions

NL: Montagehandleiding

DK: Installationsvejledning til

PL: Instrukcja montażu

EE: Paigaldusjuhised

PT: Instruções de montagem

FI: Paigaldusjuhised

RO: Instrucțiuni de asamblare

FR: Instructions de montage

SE: Monteringsanvisningar

GR: Οδηγίες συναρμολόγησης

SK: Návod na montáž

IE: Treoracha tionóil

SI: Navodila za sestavljanje

IT: Istruzioni di montaggio

ES: Instrucciones de montaje

HR: Összeszerelési útmutató


CZ: Návod k montáži

LV: Montāžas instrukcija

HU: Összeszerelési útmutató

LT: Surinkimo instrukcijos


BG: Инструкции за сглобяване



2x A




8x SC28



2x B



4x SC8-10




1x C



2x SC8-20






1x





MONTAGEANLEITUNG

sun-10507abc · Ford Capri 2024- SunClip Auto Sonnenschutz



MONTAGEANLEITUNG

sun-10507abc · Ford Capri 2024- SunClip Auto Sonnenschutz



MONTAGEANLEITUNG

sun-10507abc · Ford Capri 2024- SunClip Auto Sonnenschutz

