

## Questions about my WinClip

### 1. What is the difference between WinClip MULTI and WinClip STYLE?

The STYLE is fitted in the inner frame of the window. This means that only the fabric is visible from the outside and not the tenter frame. It is suitable for offset PVC-U windows.

The MULTI is fitted to the outside of the window. This means that the tensioning frame is visible from the outside. It is suitable for flush and (semi-)offset window types without weather louvre.

**Note:** Due to the external installation, the MULTI is produced 4 cm larger in height and width than the ordered size and requires approx. 2 cm space to the side of the masonry.

### 2. How do I measure my window correctly?

Measure the width and height of the window to the exact millimetre using a tape measure, folding ruler or folding rule - please do not use a leather tape measure / tailor's tape measure. See also the video on measuring for the STYLE or MULTI.

### 3. How do I install the WinClip?

The retaining clips only need to be cut to size and pressed onto the tensioning frame. The WinClip can then be clicked into the window (see also the installation video).

### 4. Will rubber seals be damaged during installation?

Our patented plastic holders are softer than metal clips. The rubber seals are not damaged and will deform back when the WinClip is removed.

### 5. Is the WinClip suitable for installation between windows and roller shutters?

Yes, as long as the gap between the window frame and shutters/blinds is at least 8 mm.

### 6. What is the diameter of the clamping frame and can windows be closed with it without any problems?

The WinClip tensioning frame has a diameter of approx. 5mm. Windows can be closed with the WinClip without any problems.

### 7. How do I clean the WinClip?

Dirt can be easily removed from the WinClip with a damp cloth.